

FITTING INSTRUCTIONS FOR NEW DAF BRAKE PADS WP1601 & WP1601S2, DAF 2270497, KNORR K219966K50

PLEASE NOTE: THESE BRAKE PADS ARE HANDED



EACH SHRINK WRAPPED SET INCLUDES: 1 x INBOARD Pad measures 247.5 mm 1 x OUTBOARD Pad measures 250.0 mm

1. Install the INBOARD Brake Pad



2. Install OUTBOARD Brake Pad



4. Press down on Top Springs



6. Press down on Retaining Bar and push in Retaining Pin



WINNARD
WEBSISSINBOARD
WINNARD

WINNARD
WP160152 SF8288
OUTBOARD

250.0mm

3. Install Top Springs



5. Push in Retaining Bar



7. Install washer & Double R-Clip

