



PRODUCT SERVICE INFORMATION

January 2014

WP1279 Fitting guide

Installation of Anti-Rattle Spring and Wear Warning Indicator

*NOTE: When installing hold down springs with WP1279 pad set, the spring must be installed **below** the wear warning indicator plate.*

Step 1.

Insert the wear warning indicator plugs into the brake pad backing plate as normal, and as shown in the picture below.



Step 2

Install the hold down springs onto the brake pad backing plates and the heat plate, making sure that the springs are located **underneath** the wear warning indicator plate, as shown in the picture below. Note that the springs should locate on the outside of the wear warning indicator wires as shown below.



Step 3

Insert the pad retention clamp bar into the caliper as normal and compress the springs.



Step 4

Secure the pad retention clamp bar using the bolt supplied, as normal and torque to the manufacturer's recommended torque setting.



FINISH

The picture below shows the finished installation.

